



Content

- 1. Brief description
- 2. How to lock the system
- 3. How to unlock the system
- 4. Working with / without the system
- 5. Availablity of the system
- 6. Contact and support



1. Brief description

The automatic ratchet lock system

The ratchet lock is an automatic arresting mechanism that locks the retracting cable in defined positions. It is automatically activated if the working load is moved back slowly. If pushed back fast, the mechanism remains inactive.

This represents a significant ergonomic improvement for some specific applications, for example if it is impractical to return the suspended tool fully to its initial position between jobs or working steps.


The ratchet lock feature is available for Kromer Type 7212, 7222, 7231 and 7236.



Automatic ratchet lock system by Kromer

2. How to lock the system





3. How to unlock the system



Manual: Explained: By pulling on the

Step 1

Pull the tool down a bit.

Step2


Without stopping (one movement), pull the tool straight upwards again – this time with fast speed.

Step2

Remeber:

Unlock the system with fast speed





Due to the acceleration and the associated higher centrifugal force, the pins are pushed outwards and the ratchet lock is automatically released (unlocked).

4. Working with / without the system




Working with the system

Working without the system



1. Pull down the tool and start working.

Workplace



2. Tool stays automatically at a predefined position. This ensures a tool readiness for repeating assembly steps.

Increases ergonomics at the workplace



1. Pull down the tool and start working.

Workplace



2. After work, the tool is automatically retracted to its initial position.


Workplace remains clean and safe

5. Availability of the system



Simply effective: The automatic ratchet lock system by Kromer

Availability for:









This might be also interesting for you:

- Kromer download area: User manuals, catalogs, technical drawings and more: click here.
- Kromer service videos: Cable replacement, Adjustment of suspension and more: <u>click here</u>.

Further questions?

Contact us, we are happy to help:



+49(0) 7665 50207 - 0



kromer@kromer.com



E-support



Contact us for a live-video conference. We look forward to e-meeting you.

